

We understand - new technology can be intimidating. That’s why we’ve put together this easy to use quick reference brochure for i-Guide. i-Guide unlocks a world of great choice, convenience and control so you can fully enjoy your digital cable entertainment experience.

With Family Cable, you have more programming choices than ever before. And with i-Guide, you can effortlessly find your favorite shows and stars on TV – you’re in control.

With 90-minutes of program listings at a glance, you’ll find i-Guide easy to use and navigate. The Quick Menu allows you to move easily to the programming and information you want. You’ll be able to easily set Recordings, Reminders, Favorites and Parental Controls. Use Mini Guide to browse future listings while you continue to enjoy watching TV.

This brochure provides you with the detailed information about important features in i-Guide so you can get started enjoying your digital cable experience.

i-Guide is used with the following gadgets for your home:

Motorola DCX700-HD Standard Box

Motorola DCX3510-HD DVR Box



906 Okoboji Ave
Milford, IA 51351
855-722-3450
www.milfordcomm.net

Enhance Your Digital Cable Experience

With i-Guide, you'll find it easy to find and discover the programs you love. With enhanced search capabilities and new DVR recording management tools, you can enjoy your favorites shows anytime.

Remote Control Features

Basic Navigation

- It's easy to get started. Press the GUIDE button on your remote to access the Listings By Time grid
- **Yellow** is always the highlight color. As you navigate listings, the highlight appears on screen to indicate the current selection
- Press the ◀ ▶ or ▲ ▼ arrows to move the highlight
- Press OK/Select to tune to a show or to access program information
- Press the EXIT button to return to watching TV



Digital Video Recording (DVR)

Pause live television. Rewind and replay programs. Record your favorites all season long. With DVR², you're in control from the comfort of your own home. And with dual-tuner DVR, you can watch one program while recording another.




Control Live TV

Any time you tune to a channel, the DVR starts a temporary recording. So you can PAUSE if the phone rings, REWIND the scene you missed, and FAST-FORWARD to skip what you don't want to watch.

DVR Puts You In Control

Build Your Own Personal Video Library

It's easy to record with i-Guide. Press REC on your remote anytime while watching TV for easy one-touch recording. Press  the Program Info screen to set up a one time or series recording, or even set up an auto-recording from any Search results screen.

Your Recordings Your Way

i-Guide helps you easily manage your recordings. Access the DVR Menu from on th **DVR** ick Menu or Main Menu. From here select My Recordings to view your list.



Series recordings are automatically grouped into Folders so you can quickly scroll through your list. Use the ▲ ▼ arrows to select a series and press OK/Select. Scroll through the list to find the episode you want to see.

DVR Cleanup lets you delete multiple shows at once, and DVR History keeps track of shows that were deleted. i-Guide makes it simple to organize your shows so you can enjoy watching on your schedule.

¹ Menu selections vary depending on the services your cable provider offers.

² PPV, On Demand and DVR not available in all areas. On Demand programs may not be recorded with DVR.

Copyright © 2010 Rovi Corporation. Rovi and i-Guide are trademarks of Rovi Corporation and/or its subsidiaries.



quick reference guide

Quick Menu: Quick & Easy

The Quick Menu¹ offers shortcuts to key i-Guide features. Just press MENU on your remote anytime while using the guide or watching TV, and you'll have easy access to your DVR, On Demand and HD programming, Search, and Parental Controls.



Press the ◀ ▶ arrows on your remote to highlight an option, press OK/SELECT and you're on your way.

Mini Guide

Mini Guide lets you watch television and view listings without having to leave your program. To access, press OK/Select then use the ◀ ▶ arrows to browse time and ▲ ▼ arrows to browse channels.



Smart Channel Surfing

The Flip Bar provides program information as you change channels, plus, you can even tune easily to the associated HD channel or On Demand. Press OK to select, or INFO for program details.




Parental Controls

Parental Controls allow you to restrict viewing and purchases of TV programs based on your preferences. Set a personalized 4-digit PIN to place locks on selected movie & TV ratings, TV content ratings, channels, and titles. You can also hide adult titles from being displayed on screen.



Select the lock icon from the Quick Menu to set up Parental Controls and PINs.



All Access With Main Menu

From the Main Menu,¹ you can access all i-Guide features. Press MENU twice, then select from the options, including Listings By Time, Search, DVR, Local Weather, Setup and more.


Instant Program Info

i-Guide provides Instant Information while you view program listings, including program title, start/end time, and a brief description including ratings. Helpful indicators identify settings, such as Reminders, Recordings, Locks and Favorites.



Enhanced Searching

i-Guide offers expanded search capabilities so you can find your favorite shows faster as well as discover new ones. Search by Category or by Title, Keyword or Actor/Director. Access Search from the Search icon on the Quick Menu or from the Main Menu.



Listings By Time

Press GUIDE to access Listings By Time. Channel numbers and network call letters appear on the left with times along the top. Use the ◀ ▶ ▲ ▼ arrows to navigate the lineup and to go forward in time.




Color coding makes it easy:

- Blue – Regular programs
- Purple – Movies

- Green – Sports
- Light Blue – Kids' programs

Action Icons

From the Listings By Time grid, press INFO to learn more about a program. Use the Action Icons at the bottom to set Recordings, Reminders, Parental Controls, and more.



Use the arrow ◀ ▶ buttons to highlight an icon.



When searching by Keyword, Title, or Actor/Director, use the keyboard to spell out your request. i-Guide will search for shows. You can select Save Search or set an Auto-Recording right from any Search results screen.



Go Ahead, Play Favorites

Create up to five Favorites lists – one for everyone in the family. Select the heart icon from the Quick Menu, or My Favorite Channels from the Main Menu.

quick
reference